

ROCKY MOUNTAIN WOOFUM STICK

Everything you need to know
to make your own Woofum Stick!

PARTS LIST:

- 3/16th Dia. Aluminum Rod
- 1.25" Dia. Wood Closet Rod
- Vegetable Oil

EQUIPMENT NEEDED:

- Drill or Drill Press
- 11/64th Drill Bit
- Belt Sander
- Hammer
- Chop Saw

HOW TO ASSEMBLE:

- Cut the Metal Rod into 18" lengths.
- Cut the Closet Rod into 2" lengths.
- Sand the top edge of the Wood Rod.
- Drill a 12/64" hole 1" into the center of the bottom of the Closet Rod.
- Pound the Rod into the hole of the Closet Rod.
- Soak the Closet Rod in Vegetable Oil for 24 hrs.

WHERE TO BUY ALUMINUM ROD:

- Industrial Metal Supply, 7550 Ronson Road
- East County Metal Supply, 275 Vernon Way, El Cajon
- Handy MetalMart, 1540 McKinley, National City
- Escondido Metal Supply, 1630 W. Mission, Escondido

